#### RE 27 518/02.03

Replaces: 11.02

# Double throttle check valve Type Z2FS 10

Nominal size 10 Series 3X Maximum operating pressure 315 bar Maximum flow 160 L/min



Type Z2FS 10 -5-3X/.V


#### Overview of contents

Contents	Page
Features	1
Ordering details	1
Symbols	2
Preferred types	2
Function, section	2
Technical data	3
Characteristic curves	3
Unit dimensions	4, 5

#### **Features**

- Sandwich plate valve
- Porting pattern to DIN 24 340 Form A, ISO 4401 and CETOP—RP 121 H
- For limiting the main or control fluid flow of
- 2 actuator connections
- 3 adjustment elements:
  - Lockable rotary knob with scale
- Spindle with internal hexagon and scale
- Rotary knob with scale
- , 5 For meter-in or meter-out control

# **Ordering details**






© 2003

by Bosch Rexroth AG, Industrial Hydraulics, D-97813 Lohr am Main


All rights reserved. No part of this document may be reproduced or stored, processed, duplicated or circulated using electronic systems, in any form or by any means, without the prior written authorisation of Bosch Rexroth AG. In the event of contravention of the above provisions, the contravening party is obliged to pay compensation.

Z2FS 10 **1**/6 RE 27 518/02.03

**Z2FS 10 ..-3X/..** (meter-in)



**Z2FS 10 ..-3X/..** (meter-out)



# **Preferred types** (readily available)

Туре	Material number
Z2FS 10-5-3X/V	R900517812
Z2FS 10A5-3X/S2V	R900523578
Z2FS 10A5-3X/SV	R900517813

Further preferred types and standard units can be found in the EPS (Rexroth Price List).

## **Function**, section

Valve type Z2FS 10 is a double throttle check valve of sandwich plate design.

It is used to limit the main or pilot oil flow of one or two actuators. Two symmetrically arranged throttle check valves limit the flow in one direction and allow free-flow in the opposite direction.

With meter-in control the pressure fluid passes through port A1 via the throttle area (1), that is created by the valve seat (2) and the throttle spool (3.1), to the actuator A2. The throttle spool (3.1) is axially adjustable via the adjustment screw (4) and thus enables the throttling point to be set (1).

Simultaneously the pressure fluid present in port A1 is passed to the piston side of the throttle spool (6) via drilling (5). The applied pressure, in addition to the spring force holds the throttle spool (3.1) in the throttling position.


The pressure fluid returning from actuator B2 moves the throttle spool (3.2) against the spring (7) and thus enables unrestricted flow via the check valve. Depending on the installation orientation the throttling effect may be arranged as meter-in or meter-out control.

### Limiting the main fluid flow

In order to change the velocity of an actuator (main fluid flow), the double throttle check valve is installed between the directional valve and the subplate.

#### Limiting the control fluid flow

With pilot operated directional control valves, the double throttle check valve is installed as a switching time adjustement (control fluid flow). It is fitted between the main valve and the pilot valve.



**Type Z2FS 10 –5–3X/.V** (meter-in)


# **Technical data** (for applications outside these parameters, please consult us!)

General		
Installation		Optional
Ambient temperature range	°C	−20 to +80 for FKM seals
Weight	kg	Approx. 3.1
Hydraulic		
Pressure fluid		Mineral oil (HL, HLP) to DIN 51 524; Fast bio-degradable pressure fluids to VDMA 24 568 (also see RE 90 221); HETG (rape seed oil); HEPG (polyglycols); HEES (synthetic ester); Other pressure fluids on request
Cleanliness class to ISO code		Maximum permissible degree of contamination of the pressure fluid is to ISO 4406 (C) class 20/18/15 1)
Pressure fluid temperature range	°C	−20 to +80 for FKM seals
Viscosity range	mm²/s	10 to 800
Operating pressure, max.	bar	Up to 315
Flow, max.	L/min	Up to 160


The cleanliness class stated for the components must be adhered too in hydraulic systems. Effective filtration prevents faults from occurring and at the same time increases the component service life.
For the selection of filters see catalogue sheets RE 50 070, RE 50 076 and RE 50 081.


# **Characteristic curves** (measured at $v = 41 \text{ mm}^2\text{/s}$ , $\vartheta_{\text{oil}} = 40 \text{ °C} \pm 5 \text{ °C}$ )

# Pressure differential $\Delta p$ in relation to the flow $q_{\rm V}$ across the check valve



# Pressure differential $\Delta p$ in relation to the flow $q_{\rm V}$ at a constant throttle setting






- 1 Name plate
- 2 Adjustment "5" Spindle to adjust the flow cross-section (internal hexagon 8A/F)
  - Anti-clockwise rotation = increase in flow
  - Clockwise rotation = decrease in flow
- **3** Adjustment "3"
- 4 Adjustment "7"

- **5** 4 through holes for valve fixing screws
- **6** Identical seal rings for ports A, B, P, TA, TB
- **7** R-ring plate
- **8** To change from meter-in to meter-out, rotate the unit about the "X"—"X" axis
- **9** Space required to remove the key
- 10 Only for adjustment "7"

# Valve fixing screws

M6 DIN 912-10.9, Tightening torque  $M_{\rm A}=15.5~{\rm Nm}$  must be ordered separately.




Name plate

2 Adjustment "5"
Spindle to adjust the flow crosssection
(internal hexagon 8A/F)

- Anti-clockwise rotation = increase in flow
- Clockwise rotation = decrease in flow

- **3** Adjustment "3"
- 4 Adjustment "7"
- **5** 4 through holes for valve fixing screws
- 6 Identical seal rings for ports A, B, P, TA, TB
- **7** R-ring plate
- **9** Space required to remove the key



Required surface finish of the mating piece

# Valve fixing screws

M6 DIN 912-10.9,

Tightening torque  $M_A = 15.5$  Nm must be ordered separately.

#### Bosch Rexroth AG Industrial Hydraulics

D-97813 Lohr am Main Zum Eisengießer 1 • D-97816 Lohr am Main Telefon 0 93 52 / 18-0

Telefax 0 93 52 / 18-23 58 • Telex 6 89 418-0 eMail documentation@boschrexroth.de

Internet www.boschrexroth.de

#### **Bosch Rexroth Limited**

Cromwell Road, St Neots, Cambs, PE19 2ES Tel: 0 14 80/22 32 56 Fax: 0 14 80/21 90 52 E-mail: info@boschrexroth.co.uk The data specified above only serves to describe the product. No statements concerning a certain condition or suitability for a certain application can be derived from our information.

The details stated do not release you from the responsibility for carrying out your own assessment and verification. It must be remembered that our products are subject to a natural process of wear and ageing.